

# **Somfy Motorization Programing Guide**

## **SETTING CHANNELS**

Use paperclip to touch motorhead

Three jogs with paper clip (**Up/Down, Up/Down, Up/Down**)

Go to channel to channel your programming

Hold Up/down button. Shade will jog once

Bring shade desired upper limit

Hold My & Down button

Shade will go down

Stop at desired bottom limit

Adjust bottom limit with up or down button

Use My and Up to set. Shade will go up and stop at the upper limit.

When stopped, hold MY button, shade will jog once.

Just TAP back Red button

Channel #1 is now set.

Repeat with channel #2, #3, etc if needed.

-----

### **SET ALL UP - ALL DOWN**

Go to channel #1 and hold the back red button. Shade will jog once.

Go to the hidden 5th channel and wait for lights to stop blinking.

Just TAP back Red button and shade will jog once.

Channel #1 now set for all up/down

Repeat for each channel if necessary.